
Quick start guide

1 Prepare (for in-car use)


- 1 Attach the main unit and the second screen to the back of the front seat headrests.
- 2 Connect the supplied AV cable to the AV OUT jack on the main unit and the AV IN jack on the second screen.
- 3 Connect the supplied car adaptor cable to the DC IN jacks on the main unit and the second screen, and to the car cigarette lighter socket.



1 Prepare (for domestic use)

Connect additional equipment (TV for example)

 Connect the AV OUT socket on the main unit to the video and audio sockets on a TV as shown directly. Connect the AC adaptor cable to the DC
IN Jack on the main unit and the power
outlet.



- 3 Switch on the TV and set to the correct video-in channel.
 - → You can consult the owner's manual of your TV. (If your TV does not have Audio and Video inputs, you will need to purchase a RF modulator. Please consult your dealer.)

Note:

This portable DVD player is designed with a built-in lithium battery to supply power to the player when you are on travel(charging of the DVD player only possible in the power-off mode).

² Enjoy



- 1 Slide the **ON/OFF** switch to **ON** to switch on the main unit.
- 2 Slide OPEN ▶ on the main unit.
- 3 Remove the protective card (if any) and load a disc with the label side facing up.
- 4 Close the disc compartment.
 - → Playback will start automatically. If not, press ►II/OK.
- 5 To stop playback, press ■.

Note:

During play, you can:

- Press **OPTION** to select some play options: audio, subtitle, repeat, and time display.
- Press BRIGHTNESS on the main unit or rotate BRIGHTNESS -I+ on the second screen to adjust brightness of screen to match lighting conditions.

